



KÖSTER Crisin 76 Concentrate

Concentrated, solvent free synthetic resin against capillary rising moisture in walls, independent of moisture content and salt contamination

Features

KÖSTER Crisin 76 Concentrate is a very thin, solvent free, concentrated liquid synthetic resin. It penetrates deeply into even the smallest capillaries and pores in building materials. Due to its very low density and a surface tension lower than that of water, KÖSTER Crisin 76 Concentrate displaces the water in the capillaries. Capillaries lined with KÖSTER Crisin 76 Concentrate are lined with resin and hydrophobic. The curing of the injected product is independent of the drying of the masonry. After full cure, KÖSTER Crisin 76 Concentrate remains flexible, does not decay or decompose, acts neutrally, does not effloresce, and does not affect steel reinforcement. During application and after full cure, KÖSTER Crisin 76 Concentrate is resistant to all of the usual corrosives in masonry such as acids, alkalis, and salts.

Technical Data

Density	0.91 g / cm ³
Type of effect	pore restricting/ hydrophobizing
Viscosity	10 - 15 mPa·s
Active ingredients	70%

Fields of Application

For saturation and pressureless injection for creating subsequent horizontal waterproofing against capillary rising moisture in all mineral building materials. Can be applied from inside and/or outside. Can be applied in cases of high degrees of moisture penetration and with all degrees of salt contamination.

Application

The application of KÖSTER Crisin 76 Concentrate is carried out by:

- The KÖSTER Suction Angle System for a horizontally installed damp proof course
- Installation with the KÖSTER Cartridge System

Installation with the KÖSTER Suction Angle System

Drill horizontal holes (14 mm diameter) according to the table overleaf in the lowest horizontal joint with a depth of 5 cm less than the thickness of the masonry and clean the holes by flushing with compressed air or briefly with water.

The length of the capillary rods must be at least 7 cm longer than the depth of the drill hole. Measure and cut the capillary rods accordingly. Now insert the end of the capillary rod into the suction angle's supply tank and then push the capillary rod and the suction angle together into the drill hole so that the suction angle is securely stuck in the hole. The suction angle is reusable.

The KÖSTER Capillary rods are not pre-wetted.

Place the KÖSTER Crisin 76 Concentrate cartridge in the suction

angle's clamping device, so that the supply tank fills up with KÖSTER Crisin 76 Concentrate.

The cartridges remain in the wall for 7 days. Remove cartridges after this period, empty cartridges can be removed immediately.

After applying the injection, the capillary rods remain in the masonry. Protruding ends are pulled out and cut off so that the drill holes can be sealed with KÖSTER KB Fix 5.

The suction angle system with KÖSTER Crisin Concentrate allows for quick and safe waterproofing against rising moisture.

Installation with the KÖSTER Cartridge System

1. Drill the required number of holes according to the table overleaf. The holes should be cleaned with compressed air, an industrial vacuum cleaner or, if necessary, be briefly flushed out with water. Holes should be drilled at an approximate 40° downward angle until approximately 5 cm before the end of the masonry. At least one horizontal joint should be traversed. The application can be carried out from the inside or the outside. If wall thickness is greater than 50 cm, it is recommended to drill holes from both sides to the middle.

2. After the drill holes have been cleaned, the KÖSTER Capillary Rods are inserted into the drill holes. Through this, prior filling of cavities, fissures and joints utilizing suspensions is usually not necessary. Put in the capillary rods so that approximately the first 4 cm of the drill hole are left clear. In this space, the cartridge will later be placed. Do not prewet the Capillary Rods. The capillary rods saturated with KÖSTER Crisin 76 Concentrate remain in the drill holes once the application is completed.

In case the prior filling of the masonry should be necessary, the cavities are to be filled with KÖSTER Mautrol Borehole Suspension prepared according to the respective technical guideline. Before full cure (after approximately 30 minutes up to a maximum of 3 hours) the holes are drilled out again.

3. Then put the KÖSTER Crisin 76 Concentrate cartridges in the drill holes. Do not apply in temperatures below 0 °C, apply only as long as the masonry is not frozen.

4. The cartridges remain in the wall for 7 days. Remove cartridges after this period, empty cartridges can be removed immediately. After that, the drill holes can be sealed with KÖSTER Mautrol Borehole Suspension or KÖSTER KB Fix 5.

The system's most important feature is its special adaptability to the specific requirements of the object at hand. By using the suction angle system:

The information contained in this technical data sheet is based on the results of our research and on our practical experience in the field. All given test data are average values which have been obtained under defined conditions. The proper and thereby effective and successful application of our products is not subject to our control. The installer is responsible for the correct application under consideration of the specific conditions of the construction site and for the final results of the construction process. This may require adjustments to the recommendations given here for standard cases. Specifications made by our employees or representatives which exceed the specifications contained in this technical guideline require written confirmation. The valid standards for testing and installation, technical guidelines, and acknowledged rules of technology have to be adhered to at all times. The warranty can and is therefore only applied to the quality of our products within the scope of our terms and conditions, not however, for their effective and successful application. This guideline has been technically revised; all previous versions are invalid.

- the depth of the drill hole is drastically reduced.
- the actual required drill depth can be exactly calculated and adhered to.
- the horizontal barrier can be placed directly in the horizontal joint between the first and second row of bricks.
- the holes can all be drilled from one side, even in case of greater wall thicknesses.
- time and material is saved.

Consumption

Guide value: 0.04 l / m per cm wall thickness

Consumption for the KÖSTER Cartridge System:

Wall thickness in cm up to	Drill hole spacing in cm*	Cartridges per m	Cartridges per drill hole
10	12.5	8	1**
20	12.5	8	1
30	12.5	8	1
40	9.0	11	1
50	7.5	14	1

* Drill hole diameter: 14 mm, Spacing from hole center to hole center:

** For wall thicknesses up to 20 cm a half filled cartridge per drill hole is sufficient. Use the KÖSTER Suction Angle System for walls over 24 cm thick.

Maximum consumption for the KÖSTER Suction Angle System:

Wall thickness in cm up to	Drill hole spacing in cm*	Cartridges per m	Cartridges per drill hole	Consump- tion capillary rods (45 cm)
20	12.5	8	1	4
30	12.5	8	1	6
40	12.5	8	1	7
50	10.0	10	1	12
60	8.5	12	1	15
70	7.0	14	1	21
80	6.3	16	1	27
90	5.5	18	1	35
100	5.0	20	1	41

* Drill hole diameter: 14 mm, Spacing from hole center to hole center:

Packaging

M 279 005	5 l jerrycan
M 279 010	10 l jerrycan
M 279 200	200 ml cartridge = 28 cartridges per carton

Storage

In originally sealed packages the material can be stored for a minimum of 6 months. Store frost free.

Safety

Wear gloves and goggles when processing the material. Observe all governmental, state, and local safety regulations when processing the material.

Other

Please be aware: After the installation of KÖSTER Crisin 76 Concentrate salts can effloresce on the surface due to the drying process. We suggest the use of KÖSTER Polysil TG 500 and the installation of a KÖSTER Restoration Plaster.

Related products

KÖSTER KB-FIX 5	Prod. code C 515 015
KÖSTER Polysil TG 500	Prod. code M 111
KÖSTER Mautrol Borehole Suspension	Prod. code M 150 024
KÖSTER Restoration Plaster 1 Grey	Prod. code M 661 025
KÖSTER Restoration Plaster 2 White	Prod. code M 662 025
KÖSTER Restoration Plaster 2 Fast	Prod. code M 663 030
KÖSTER Suction Angle	Prod. code M 930 001
KÖSTER Capillary Rods	Prod. code M 963
KÖSTER Protimeter	Prod. code M 999 001

The information contained in this technical data sheet is based on the results of our research and on our practical experience in the field. All given test data are average values which have been obtained under defined conditions. The proper and thereby effective and successful application of our products is not subject to our control. The installer is responsible for the correct application under consideration of the specific conditions of the construction site and for the final results of the construction process. This may require adjustments to the recommendations given here for standard cases. Specifications made by our employees or representatives which exceed the specifications contained in this technical guideline require written confirmation. The valid standards for testing and installation, technical guidelines, and acknowledged rules of technology have to be adhered to at all times. The warranty can and is therefore only applied to the quality of our products within the scope of our terms and conditions, not however, for their effective and successful application. This guideline has been technically revised; all previous versions are invalid.